BARGE DOCKING AND MOORING AREAS

Rev. 3.2024

TYPES OF AREAS USED IN SLLAS

- Fa<u>cilities Area: for permanent structures only.</u> Also the area
 of a body of water between the structure and the edge of
 water. No one else can use this space. The owner is paying
 for it. Do not try to straighten the irregular waters edge on
 the drawings. Straight lines are used only to simplify
 calculations of facilities areas.
- Mooring Area: used for barges only because barges are not permanent structures and can be moved around. Mooring areas are calculated using the maximum number of barges moored at one time. This information must be provided by the owner.



