E&S WORKSHEET #11

Channel Design Data

PROJECT NAME: ___ATLANTIC SUNRISE PROJECT - COMPRESSOR STATION 610_

LOCATION: ORANGE TOWNSHIP, COLUMBIA COUNTY, PENNSYLVANIA

PREPARED BY: AOE DATE: 03/07/16

CHECKED BY: ______ DATE: ______ DATE: _______

ONEONED BY: AUB			DATE: <u>03/07/10</u>				
CHANNEL OR CHANNEL SECTION		DITCH 1 R-4 RIP RAP	DITCH 2A R-4 RIP RAP	DITCH 2B R-4 RIP RAP	DITCH 3 R-4 RIP RAP	DITCH 4 R-4 RIP RAP	
TEMPORARY OR PERMANENT?	/T OD D)	LINING	LINING	LINING P	LINING P	LINING P	
	(T OR P)	P 40	P 10	'		·	
ACRES	2, 5, OR 10 YR)	10	10	10	10	10	
	(AC)	0.36	1.83	1.34	0.35	1.00	
MULTIPLIER ¹ (1.6, Qr (REQUIRED CAPACITY)	2.25, or 2.75) ¹	2.75	2.75	2.75	2.75	2.75	
,	(CFS)	0.99	5.03	3.69	0.96	2.75	
Q (CALCULATED AT FLOW DEPTH d)	(CFS)	1.00	5.06	3.72	1.00	2.77	
PROTECTIVE LINING ²		R-4 RIP RAP	R-4 RIP RAP	R-4 RIP RAP	R-4 RIP RAP	R-4 RIP RAP	
n (MANNING'S COEFFICIENT) ²		0.064	0.059	0.063	0.064	0.064	
Va (ALLOWABLE VELOCITY)	(FPS)	9	9	9	9	9	
V (CALCULATED AT FLOW DEPTH d)	(FPS)	0.99	2.64	2.42	1.76	2.55	
та (MAX ALLOWABLE SHEAR STRESS)	(LB/FT ²)	N/A	N/A	N/A	N/A	N/A	
TID (CALC'D SHEAR STRESS AT FLOW DEPTH	ld) (LB/FT ²)	0.23	1.35	1.30	0.78	1.53	
CHANNEL BOTTOM WIDTH	(FT)	2	2	2	2	2	
CHANNEL SIDE SLOPES	(H:V)	2	2	2	2	2	
D (TOTAL DEPTH)	(FT)	2.0	2.0	2.0	2.0	2.0	
CHANNEL TOP WIDTH @ D	(FT)	10	10	10	10	10	
d (CALCULATED FLOW DEPTH)	(FT)	0.37	0.60	0.51	0.23	0.39	
CHANNEL TOP WIDTH @ FLOW DEPTH d	(FT)	3.48	4.40	4.04	2.92	3.56	
BOTTOM WIDTH: FLOW DEPTH RATIO	(12:1 MAX)	5.41	3.33	3.92	8.70	5.13	
d50 STONE SIZE	(IN)	6	6	6	6	6	
A (CROSS-SECTIONAL AREA)	(SQ. FT.)	1.01	1.92	1.54	0.57	1.08	
R (HYDRAULIC RADIUS)		0.28	0.41	0.36	0.19	0.29	
S (BED SLOPE) ³	(FT/FT)	0.01	0.036	0.041	0.054	0.063	
Sc (CRITICAL SLOPE)	(FT/FT)	0.115	0.076	0.091	0.115	0.098	
.7Sc	(FT/FT)	0.081	0.053	0.064	0.081	0.069	
1.3Sc	(FT/FT)	0.150	0.099	0.118	0.150	0.127	
STABLE FLOW?	(Y/N)	Y	Υ	Υ	Υ	Υ	
FREEBOARD BASED ON UNSTABLE FLOW	(FT)	0.03	0.12	0.09	0.03	0.07	
FREEBOARD BASED ON STABLE FLOW	(FT)	0.50	0.50	0.50	0.50	0.50	
MINIMUM REQUIRED FREEBOARD ⁴	(FT)	0.50	0.50	0.50	0.50	0.50	
DESIGN METHOD FOR PROTECTIVE LINING PERMISSIBLE VELOCITY (V) OR SHEAR STRI		V	V	V	V	V	

^{1.} Use 1.6 for Temporary Channels; 2.25 for Temporary Channels in Special Protection (HQ or EV) Watersheds; 2.75 for Permanent Channels. For Rational Method, enter "N/A" and attach E&S Worksheets 9 and 10. For TR-55 enter "N/A" and attach appropriate Worksheets.

Source: 363-2134-008 / March 31, 2012 / Page 382

^{2.} Adjust "n" value for changes in channel liner and flow depth. For vegetated channels, provide data for manufactured linings without vegetation and with vegetation in separate columns.

^{3.} Slopes may not be averaged.

^{4.} Minimum Freeboard is 0.5 ft. or 1/4 Total Channel Depth, whichever is greater

^{5.} Permissible velocity lining design method is not acceptable for channels with a bed slope of 10% or greater. Shear stress lining design method is required for channels with a bed slope of 10% or greater. Shear stress lining design method may be used for any channel bed slope.

E&S WORKSHEET #11

Channel Design Data

PROJECT NAME: ___ATLANTIC SUNRISE PROJECT - COMPRESSOR STATION 610_

LOCATION: ___ORANGE TOWNSHIP, COLUMBIA COUNTY, PENNSYLVANIA_

OIILONED D1		D/(1202/				
CHANNEL OR CHANNEL SECTION		DITCH 5 R-4 RIP RAP LINING	DITCH 6 R-4 RIP RAP LINING	DITCH 7 R-4 RIP RAP LINING	DITCH 8 R-4 RIP RAP LINING	
TEMPORARY OR PERMANENT?	(T OR P)	P	P	P	Р	
DESIGN STORM	2, 5, OR 10 YR)	10	10	10	10	
ACRES	(AC)	0.40	7.59	0.10	0.42	
MULTIPLIER ¹ (1.6	6, 2.25, or 2.75) ¹	2.75	2.75	2.75	2.75	
Qr (REQUIRED CAPACITY)	(CFS)	1.10	20.87	0.28	1.16	
Q (CALCULATED AT FLOW DEPTH d)	(CFS)	1.15	20.91	0.21	1.19	
PROTECTIVE LINING ²		R-4 RIP RAP	R-4 RIP RAP	R-4 RIP RAP	R-4 RIP RAP	
n (MANNING'S COEFFICIENT) ²		0.064	0.045	0.064	0.064	
Va (ALLOWABLE VELOCITY)	(FPS)	9	9	9	9	
V (CALCULATED AT FLOW DEPTH d)	(FPS)	0.99	3.04	1.20	1.52	
та (MAX ALLOWABLE SHEAR STRESS)	(LB/FT ²)	N/A	N/A	N/A	N/A	
тd (CALC'D SHEAR STRESS AT FLOW DEPTH	d) (LB/FT ²)	0.23	0.97	0.44	0.56	
CHANNEL BOTTOM WIDTH	(FT)	2	2	2	2	
CHANNEL SIDE SLOPES	(H:V)	2	2	2	2	
D (TOTAL DEPTH)	(FT)	2.0	2.0	2.0	2.0	
CHANNEL TOP WIDTH @ D	(FT)	10	10	10	10	
d (CALCULATED FLOW DEPTH)	(FT)	0.41	1.42	0.08	0.30	
CHANNEL TOP WIDTH @ FLOW DEPTH d	(FT)	3.64	7.68	2.32	3.20	
BOTTOM WIDTH: FLOW DEPTH RATIO	(12:1 MAX)	4.88	1.41	25.00	6.67	
d50 STONE SIZE	(IN)	6	6	6	6	
A (CROSS-SECTIONAL AREA)	(SQ. FT.)	1.16	6.87	0.17	0.78	
R (HYDRAULIC RADIUS)		0.30	0.82	0.07	0.23	
S (BED SLOPE) ³	(FT/FT)	0.009	0.011	0.088	0.030	
Sc (CRITICAL SLOPE)	(FT/FT)	0.112	0.037	0.145	0.111	
.7Sc	(FT/FT)	0.078	0.026	0.101	0.078	
1.3Sc	(FT/FT)	0.146	0.048	0.188	0.144	
STABLE FLOW?	(Y/N)	Y	Υ	Y	Y	
FREEBOARD BASED ON UNSTABLE FLOW	(FT)	0.03	0.32	0.01	0.03	
FREEBOARD BASED ON STABLE FLOW	(FT)	0.50	0.50	0.50	0.50	
MINIMUM REQUIRED FREEBOARD ⁴	(FT)	0.50	0.50	0.50	0.50	
DESIGN METHOD FOR PROTECTIVE LINING PERMISSIBLE VELOCITY (V) OR SHEAR STRE		V	V	V	٧	

^{1.} Use 1.6 for Temporary Channels; 2.25 for Temporary Channels in Special Protection (HQ or EV) Watersheds; 2.75 for Permanent Channels. For Rational Method, enter "N/A" and attach E&S Worksheets 9 and 10. For TR-55 enter "N/A" and attach appropriate Worksheets.

Source: 363-2134-008 / March 31, 2012 / Page 382

^{2.} Adjust "n" value for changes in channel liner and flow depth. For vegetated channels, provide data for manufactured linings without vegetation and with vegetation in separate columns.

^{3.} Slopes may not be averaged.

^{4.} Minimum Freeboard is 0.5 ft. or 1/4 Total Channel Depth, whichever is greater

^{5.} Permissible velocity lining design method is not acceptable for channels with a bed slope of 10% or greater. Shear stress lining design method is required for channels with a bed slope of 10% or greater. Shear stress lining design method may be used for any channel bed slope.

E&S WORKSHEET #11

Channel Design Data

PROJECT NAME: <u>ATLANTIC SUNRISE PROJECT - COMPRESSOR</u>	STATION 610
LOCATION:ORANGE TOWNSHIP, COLUMBIA COUNTY, PENNSYL	VANIA
PREPARED BY: AOE	DATE: <u>02/05/17</u>

CHECKED BY: AJB DATE: 02/05/17

CHECKED BY: AJB			DATE: _	02/05/17	
CHANNEL OR CHANNEL SECTION		DITCH 9A R-4 RIP RAP LINING			
TEMPORARY OR PERMANENT?	(T OR P)	P			
DESIGN STORM	(2, 5, OR 10 YR)	10			
ACRES	(AC)	4.03			
MULTIPLIER ¹ (°	1.6, 2.25, or 2.75) ¹	2.75			
Qr (REQUIRED CAPACITY)	(CFS)	11.08			
Q (CALCULATED AT FLOW DEPTH d)	(CFS)	11.07			
PROTECTIVE LINING ²		R-4 RIP RAP			
n (MANNING'S COEFFICIENT) ²		0.051			
Va (ALLOWABLE VELOCITY)	(FPS)	9			
V (CALCULATED AT FLOW DEPTH d)	(FPS)	3.78			
та (MAX ALLOWABLE SHEAR STRESS)	(LB/FT ²)	N/A			
тd (CALC'D SHEAR STRESS AT FLOW DEP)	(LB/FT^2)	2.02			
CHANNEL BOTTOM WIDTH	(FT)	2			
CHANNEL SIDE SLOPES	(H:V)	2			
D (TOTAL DEPTH)	(FT)	2.0			
CHANNEL TOP WIDTH @ D	(FT)	10			
d (CALCULATED FLOW DEPTH)	(FT)	0.81			
CHANNEL TOP WIDTH @ FLOW DEPTH d	(FT)	5.24			
BOTTOM WIDTH: FLOW DEPTH RATIO	(12:1 MAX)	2.47			
d50 STONE SIZE	(IN)	6			
A (CROSS-SECTIONAL AREA)	(SQ. FT.)	2.93			
R (HYDRAULIC RADIUS)		0.52			
S (BED SLOPE) ³	(FT/FT)	0.040			
Sc (CRITICAL SLOPE)	(FT/FT)	0.050			
.7Sc	(FT/FT)	0.035			
1.3Sc	(FT/FT)	0.066			
STABLE FLOW?	(Y/N)	N			
FREEBOARD BASED ON UNSTABLE FLOW	(FT)	0.23			
FREEBOARD BASED ON STABLE FLOW	(FT)	0.50			
MINIMUM REQUIRED FREEBOARD ⁴	(FT)	0.50			
DESIGN METHOD FOR PROTECTIVE LINING PERMISSIBLE VELOCITY (V) OR SHEAR ST		V			

- 1. Use 1.6 for Temporary Channels; 2.25 for Temporary Channels in Special Protection (HQ or EV) Watersheds; 2.75 for Permanent Channels. For Rational Method, enter "N/A" and attach E&S Worksheets 9 and 10. For TR-55 enter "N/A" and attach appropriate Worksheets.
- 2. Adjust "n" value for changes in channel liner and flow depth. For vegetated channels, provide data for manufactured linings without vegetation and with vegetation in separate columns.
- 3. Slopes may not be averaged.
- 4. Minimum Freeboard is 0.5 ft. or 1/4 Total Channel Depth, whichever is greater
- 5. Permissible velocity lining design method is not acceptable for channels with a bed slope of 10% or greater. Shear stress lining design method is required for channels with a bed slope of 10% or greater. Shear stress lining design method may be used for any channel bed slope.

Source: 363-2134-008 / March 31, 2012 / Page 382