

DW Module 8:  
Distribution  
**Answer Key**

**Unit 1:**



**Unit 1 Exercise**

1. To become certified in distribution systems, a person must:
  - a. Successfully complete the "Water Class E – Distribution System" certification examination.
  - b. Meet work and educational experience qualifications.
  - c. Submit an application along with a criminal background check to the Certification Board. The certification board will review the application and determine if the application should be approved.
  
2. Give an example of an action which will impact the water quality or water quantity and must be made by a certified operator or by another person following standard operating procedures written and approved by the certified operator for the system:

If an operator wanted to divert more water flow in a system toward a tank, and as a result, they closed some valves to accomplish this objective. This action caused an increase in quantity of water in that particular section of main line and therefore is considered a process control decision.

3. Please determine whether a **certified operator, system owner, or Certification Board** is responsible for each of the following actions:

Action:

Approve a new application for certification: Certification Board

Report any situations causing a violation to the system owner: Certified Operator

A process control decision: Certified Operator

Respond to a certified operator report: System owner

<b>Unit 2:</b>
----------------

**Example 2.2 – Pressure Head Calculation**

How many feet of water would be in a tank if the pressure gauge at the base of the tank read 15 psi?

$$\begin{aligned} \text{ft} &= \frac{2.31 \text{ ft}}{1 \text{ psi}} \times 15 \text{ psi} \\ &= (2.31) (15) \\ &= 35 \text{ Feet} \end{aligned}$$

**Example 2.3 – Pressure Head Calculation**

What would the pressure head in psi be on a fire hydrant if a pressure gauge on that fire hydrant read 258 feet?

$$\text{psi} = \frac{1 \text{ psi}}{2.31 \text{ ft}} \times 258 \text{ ft} = 111.7 \text{ psi}$$

**Example 2.4 – Pressure Head Calculation**

What is the pressure (in psi) at a point 12 feet below the surface?

$$\text{psi} = \frac{1 \text{ psi}}{2.31 \text{ ft}} \times 12 \text{ ft} = 5.2 \text{ psi}$$

**Unit 2 Exercise**

1. Circle those items that are components of a distribution network.
  - a. Pumps
  - c. Storage Facilities
  - d. Intake
  - f. Pipes

- g. Hydrants
- h. Valves
- j. Meters

**Trench Safety fill in the blank**

- 2. OSHA requires a protective system for trenches 5 feet or greater.
- 3. Atmospheres containing oxygen levels below 19.5 % may be hazardous.
- 4. A stairway, ladder, ramp or other safe means of egress shall be located in trench excavations that are 4 feet or more in depth so as to require no more than 25 feet of lateral travel for employees.

**New main installation fill in the blank**

- 5. Haunching – the portion of the material placed in an excavation on either side of and under a pipe from the top of the bedding up to the springline or horizontal centerline of the pipe. This backfill layer extends from one trench sidewall to the opposite sidewall. This is the most critical area in providing support for a pipe.
- 6. To minimize settling, during a backfill operation, it is recommended that after every 12 inches of lift, material should be compacted.
- 7. The 4 crucial steps that are necessary before putting a new main in service:
  - 1. Disinfect
  - 2. Pressure Test
  - 3. Flush
  - 4. Perform Bacteriological Test

**Valve Matching**

Use word bank to fill in the blanks in 8 through 13

Butterfly valve	Altitude valve	Gate valve	Pressure Reducing valve
	Air release valves	Check valves	

8. Check Valves are used in distribution systems to prevent back flows.
9. Pressure Reducing Valves are used to create headloss and “break” pressure to keep system pressures less than the pressure ratings in pipes and to avoid other adverse impacts of high pressure.
10. Gate Valves are the most commonly used isolation valve.
11. Butterfly valves are a flow control valve that can be adjusted to allow various flows through piping.
12. Air release valves are used to eliminate air from a distribution network or to allow air into a distribution network.
13. Altitude valve is a type of valve used to control flow in and out of storage facilities based on water level.

**Random Multiple Choice**

14. Corporation stops are typically tapped at:
  - a. 10:00 o'clock position
  - b. 11:00 o'clock position
  - c. 12:00 o'clock position
  - d. 1:00 o'clock position
15. Rapid changes in flow velocity within a distribution network can result in:
  - e. Water hammer
  - f. Pipe bursting
  - g. Failure of distribution network component
  - h. All of the above
16. Commonly used as a customer service meter:
  - i. Velocity
  - j. Compound
  - k. Displacement
  - l. Proportional
17. A flow of \_\_\_\_\_ can easily be identified if the top of the hydrant is painted blue.
  - a. Below 500 gpm
  - b. 500-9999 gpm
  - c. 1000 -1499 gpm
  - d. 1500 gpm or more

18. The pressure gauge at the bottom of the tank reads 12 psi. How many feet of water would you expect in the tank?
- a. About 2 feet
  - b. About 5 feet
  - c. About 28 feet
  - d. About 60 feet
19. Thrust blocks or restraints should be used at \_\_\_\_\_ to avoid movements and leaks:
- a. Tees
  - b. Bends
  - c. Hydrants
  - d. All of the above
20. List the five programs involved in routine maintenance of distribution networks.
- a. Pump Maintenance
  - b. Valve Maintenance
  - c. Meter Testing and Maintenance
  - d. Fire Hydrant Maintenance
  - e. Inspection and Monitoring

### Unit 3:



#### Example 3.1 – Volume Calculation

A rectangular ground level storage facility is 100 feet long by 50 feet wide. The water level in the tank (measured from the bottom of the tank) is 10 feet. What is the volume (in gallons) of water in the tank?

$V = (l) \times (w) \times (h)$ , where h is the height of water in the tank

$$V = 100 \text{ ft} \times 50 \text{ ft} \times 10 \text{ ft}$$

$$V = 50,000 \text{ cubic feet}$$

There are 7.48 gallons in a cubic foot. Thus,

$$V = 50,000 \text{ cubic feet} \times 7.48 \text{ gallons/cubic foot}$$

$$V = 374,000 \text{ gallons}$$

**Example 3.2 – Volume Calculation**

An elevated tank has a diameter of 50 feet. The water level in the tank is 20 feet. What is the volume of water in the tank?

$$V = (A) \times (h), \text{ where } A = \pi \times \text{Radius } (r)^2 \quad \text{or} \quad V = (0.785) \times (\text{Dia})^2 \times H$$

$$V = (3.14 \times 25^2) \times 20$$

$$V = (0.785) \times (50)^2 \times 20$$

$$V = 39,250 \text{ cubic feet}$$

$$V = 0.785 \times 2500 \times 20 = 39,250 \text{ cubic feet}$$

One cubic foot = 7.48 gallons, so we can calculate the volume to be:

$$V = 39,250 \text{ ft}^3 \times 7.48 = 293,590 \text{ gallons}$$

Another example of distribution “storage” is the volume of water contained in the pipes themselves. The volume of water in a pipe can be calculated using the same formula as above:

$\text{vol} = (0.785)(\text{dia})^2(\text{length})(7.48\text{gal}/\text{ft}^3)$ , substituting the length of pipe for the height of water

**Example 3.3 – Volume Calculation**

How many gallons of water are in a 400 foot section of main that has an 8 inch diameter?

First step:

Convert 8 inch to feet

$$\text{Feet} = \frac{8 \text{ in}}{12 \text{ in}} = 0.67 \text{ feet}$$

Second step:

Plug into volume formula

$$\begin{aligned} \text{Vol} &= (0.785) \times (\text{diameter})^2 \times (\text{length}) \\ &= (0.785) \times (0.67 \text{ feet})^2 \times 400 \text{ feet} \\ &= 141 \text{ ft}^3 \end{aligned}$$

Third step:

Convert  $\text{ft}^3$  to gallons

$$\text{Gallons} = 141 \text{ ft}^3 \times 7.48 = 1,055 \text{ gallons}$$

**Example 3.4 – Volume Calculation**

The diameter of a tank is 60 feet. Without refilling of the tank, in one day, the water depth dropped from 25 feet to 21 feet, how many gallons of water were used that day?

First step:

$$\text{Height} = 25 \text{ ft} - 21 \text{ ft} = 4 \text{ ft}$$

Second step:

$$V = (0.785) \times (\text{diameter})^2 \times (\text{height})$$

$$V = (0.785) \times (60 \text{ ft})^2 \times (4 \text{ ft}) = 11,304 \text{ ft}^3$$

Third step:

Convert  $\text{ft}^3$  to gallons

$$\text{Gallons} = 11,304 \text{ ft}^3 \times 7.48 = 84,554 \text{ gallons}$$



### Unit 3 Exercise

1. List the three primary functions of distribution storage facilities.

- 1) Equalize demand and pressures
- 2) Fire Protection
- 3) Emergency Supply

2. What are some advantages to using an elevated storage tank?

Elevated storage facilities are typically used to boost pressure in distribution systems

3. Explain the procedures and methods used in controlling the filling and draining of a distribution storage facility that you are familiar with.

*[Answer is as per the student's experience.]*

4. List three maintenance issues concerning distribution storage facilities.

- 1) Painting
- 2) Corrosion Control
- 3) Water Quality

5. A new section of 12 inch diameter pipe is to be disinfected before it is put into service. If the length of pipeline is 2000 feet, how many gallons of water will be needed to fill the pipeline?

First step:

Convert 12 inch to feet

$$\text{Feet} - \underline{12 \text{ in}} = 1 \text{ feet}$$

12 in

Second step:

Plug into volume formula

$$\begin{aligned}\text{Vol} &= (0.785) \times (\text{diameter})^2 \times (\text{length}) \\ &= (0.785) \times (1 \text{ feet})^2 \times 2000 \text{ feet} \\ &= 1,570 \text{ ft}^3\end{aligned}$$

Third step:

Convert  $\text{ft}^3$  to gallons

$$\text{Gallons} = 1,570 \text{ ft}^3 \times 7.48 = \mathbf{11,744 \text{ gallons}}$$

## Unit 4:



### Example 4.1 – Dosage Calculation

The chlorine residual is 0.7 mg/l, and the demand is 0.5 mg/l. What is the dose?

$$\text{Dose} = \text{demand} + \text{residual} = 0.7 + 0.5 = 1.2 \text{ mg/l}$$



### Example 4.2 – Dosage Calculation

The chlorine dose is 2.1 mg/l, and the demand is 0.9 mg/l. What is the residual?

$$\text{Rearrange} = \text{Chlorine Residual} = \text{Chlorine Dosage} - \text{Chlorine Demand}$$

$$\text{So, } 2.1 - 0.9 = 1.2 \text{ mg/l}$$



### Example 4.4 – Dosage Calculation

A system has repaired the storage facility. They need to disinfect it before putting it back in service. They are going to use 25 mg/l of chlorine. How many pounds of 65% calcium hypochlorite are required if the storage facility has a 50 foot diameter and is 75 feet tall?

First step:

Plug into volume formula



$$\begin{aligned}\text{Vol} &= (0.785) \times (\text{diameter})^2 \times (\text{length}) \\ &= (0.785) \times (50 \text{ feet})^2 \times 75 \text{ feet} \\ &= 147,188 \text{ ft}^3\end{aligned}$$

Second step:

Convert  $\text{ft}^3$  to gallons

$$\text{Gallons} = 147,188 \text{ ft}^3 \times 7.48 = 1,100,963 \text{ gallons}$$

Third step:


Now, convert the 1,100,963 gallons to a MGD unit by dividing by 1,000,000 gallons

$$\frac{1,100,963 \text{ gal}}{1,000,000 \text{ gal}} = 1.1 \text{ MGD}$$

Fourth step:

Plug into "pounds formula"

$$\begin{aligned}\text{Pounds/day} &= \text{flow(MG)} \text{ dose(mg/l)}(8.34) \\ &= (1.1)(25)(8.34) \\ &= 229 \text{ pounds}\end{aligned}$$



Last step:

Calculate the amount of 65% calcium hypochlorite needed factoring in the purity:

$$\frac{229}{0.65} = 353 \text{ pounds}$$



#### Unit 4 Exercise

1. Write the two immediate steps required after a bacteria test is positive for total coliform:
  - a. The laboratory will run a fecal and/or e-coli
  - b. The system will collect check samples
2. Select the best response to complete the following true statement. Chlorine is added to a water system and is maintained throughout the distribution system to:
  - a. Protect public health.
  - b. Prevent corrosion.
  - c. Reduce public confidence.
  - d. Increase taste and odor.
3. The initial chlorine demand of the impurities in a source of water is 1.5 mg/l. What is the chlorine dosage required to produce a chlorine residual of 2.0 mg/l?

3.5 mg/l

4. What is the recommended minimum water velocity when flushing water distribution piping?

5 fps

5. List five problems associated with stagnation of water due to dead ends:

- a. Depleted disinfectant residual
- b. Bacteriological issues
- c. Turbidity
- d. Color/tastes/Odor Issues
- e. Iron/Manganese Sediment

6. A system has replaced 350 feet of 12 inch water main. They are going to use 50 mg/l of chlorine for 24 hours to disinfect the line. How many pounds of 65% calcium hypochlorite are required?

First step:

Convert 12 inch to feet  
Feet –  $\frac{12 \text{ in}}{12 \text{ in}} = 1 \text{ foot}$

Second step:

Plug into volume formula  
 $\text{Vol} = (0.785) \times (\text{diameter})^2 \times (\text{length})$   
 $= (0.785) \times (1 \text{ feet})^2 \times 350 \text{ feet}$   
 $= 275 \text{ ft}^3$

Third step:

Convert  $\text{ft}^3$  to gallons  
Gallons =  $275 \text{ ft}^3 \times 7.48 = 2055 \text{ gallons}$

(See next page for Forth step)

Forth step:


Now, convert the 527 gallons to a MGD unit by dividing by 1,000,000 gallons

$$\frac{2055}{1,000,000} \text{ gal} = 0.0021 \text{ MGD}$$

Fifth step:

Plug into "pounds formula"

$$\begin{aligned} \text{Pounds/day} &= \text{flow(MG)} \text{ dose(mg/l)}(8.34) \\ &= (0.0021)(50)(8.34) \\ &= 0.9 \text{ pounds} \end{aligned}$$



Last step:

Calculate the amount of 65% calcium hypochlorite needed factoring in the purity:

$$\frac{0.9}{0.65} = 1.3 \text{ pounds}$$